



Tent Pitching Instructions Spirit 200+ & 300+

Flysheet First Pitching

1. Assemble the three poles and lay them on the ground.
2. Open flysheet on ground and position tent in desired direction.
3. Locate black pole sleeves on outside of flysheet and insert poles. The pole sleeve ends are colour matched to the poles.
4. Locate one end of each pole into corresponding eyelets on pole anchor straps.
5. Push poles into an arch from opposite side and locate pole ends into corresponding eyelets.
6. Tighten the flysheet by adjusting the tension straps at the base of the poles.
7. Peg out adjustable anchor straps at both corners of the rear of the tent, using alloy pin pegs.
8. Pull the tent forwards, away from pegged points, until tent takes shape. Peg the two anchor straps at the front of the tent.
9. Peg down pole anchor straps and remaining flysheet pegging points.
10. Peg out ALL guy lines using the Y alloy pegs.

The inner tent and flysheet can remain attached when pitching or packing. However, in humid or very wet weather, the underside of the flysheet may be coated with condensation. If this occurs, it may be advisable to detach the inner and pack it separately to avoid the inner tent becoming wet.

Inner Tent (if previously removed)

1. Open out inner tent inside flysheet and position doorway to correspond with the porch entrance of the flysheet.
2. Starting from the rear corners of the tent, attach the elasticated hooks on the groundsheet to corresponding rings on the flysheet.
3. Suspend the inner by attaching elastic of inner tent with clips on inside of flysheet

Tension Band System

1. Remove Tension Band System from pockets at apex of poles. Hook the rings at the end of each line over the ends of the poles at the base of the tent
2. DO NOT OVERTENSION. Excess tension will alter the shape of the tent and may permanently distort the poles.

